

# ASSEMBLY INSTRUCTION

## MODEL : HOME 1008 KING BED - 4 PCS WOODEN SUPPORT LEGS

Before you begin, please follow Assembly Instruction carefully. Follow them step by step.

**STEP 1**

(A) M6 X 20MM JCBC SCREW - 4 PCS  
 (D) M6 X 50MM JCBC SCREW - 2 PCS  
 (G) M4 ALLEN KEY - 1 PC  
 (B) WOOD DOWEL M10 X 40MM - 4 PCS

**STEP 2**

(A) M6 X 20MM JCBC SCREW - 4 PCS  
 (D) M6 X 50MM JCBC SCREW - 2 PCS  
 (G) M4 ALLEN KEY - 1 PC  
 (B) WOOD DOWEL M10 X 40MM - 4 PCS

**STEP 3**

(A) M6 X 20MM JCBC SCREW - 8 PCS  
 (G) M4 ALLEN KEY - 1 PC

**STEP 4**

(C) M6 X 35MM JCBC SCREW - 4 PCS  
 (D) M6 X 50MM JCBC SCREW - 4 PCS  
 (E) M6 HEX NUTS - 4 PCS  
 (F) SPRING WASHER M6 - 4 PCS  
 (G) M4 ALLEN KEY - 1 PC

# ASSEMBLY INSTRUCTION

## MODEL : HOME 1008 KING BED - 4 PCS WOODEN SUPPORT LEGS

Before you begin, please follow Assembly Instruction carefully. Follow them step by step.

**STEP 5**

(D) M6 X 50MM JCBC SCREW - 4 PCS  
 (G) M4 ALLEN KEY - 1 PC

PART LIST		

HARDWARE LIST		

