

# ASSEMBLY INSTRUCTION

## MODEL : HOME 1008 QUEEN BED - 4 PCS WOODEN SUPPORT LEGS

Before you begin, please follow Assembly Instruction carefully. Follow them step by step.

**STEP 1**

(A) M6 X 20MM JCBC SCREW - 4 PCS  
 (B) WOOD DOWEL M10 X 40MM - 4 PCS  
 (D) M6 X 50MM JCBC SCREW - 2 PCS  
 (G) M4 ALLEN KEY - 1 PC

**STEP 2**

(A) M6 X 20MM JCBC SCREW - 4 PCS  
 (B) WOOD DOWEL M10 X 40MM - 4 PCS  
 (D) M6 X 50MM JCBC SCREW - 2 PCS  
 (G) M4 ALLEN KEY - 1 PC

**STEP 3**

(A) M6 X 20MM JCBC SCREW - 8 PCS  
 (G) M4 ALLEN KEY - 1 PC

**STEP 4**

(C) M6 X 35MM JCBC SCREW - 4 PCS  
 (D) M6 X 50MM JCBC SCREW - 4 PCS  
 (E) M6 HEX NUTS - 4 PCS  
 (F) SPRING WASHER M6 - 4 PCS  
 (G) M4 ALLEN KEY - 1 PC

# ASSEMBLY INSTRUCTION

## MODEL : HOME 1008 QUEEN BED - 4 PCS WOODEN SUPPORT LEGS

Before you begin, please follow Assembly Instruction carefully. Follow them step by step.

**STEP 5**

(D) M6 X 50MM JCBC SCREW - 4 PCS  
 (G) M4 ALLEN KEY - 1 PC

PART LIST		
1) HEAD POST X 2 PCS	2) FOOT POST X 2 PCS	6) CENTER RAIL X 1PC
3) HEADBOARD/ FOOTBOARD X 2 PCS	TOP RAIL X 2 PCS	7) METAL SIDE RAIL ( WITH 26 HOLES ) X 2 PCS
5) MIDDLE RAIL X 2 PCS	8) WOODEN CENTER SUPPORT LEGS X 4 PCS	

**FULL SETUP**

HARDWARE LIST	
(A) M6 X 20MM JCBC SCREW - 16 PCS	(D) M6 X 50MM JCBC SCREW - 12 PCS
(B) WOOD DOWEL M10MM X 40MM - 8 PCS	(E) M6 HEX NUTS - 4 PCS
(C) M6 X 35MM JCBC SCREW - 4 PCS	(F) SPRING WASHER M6 X 4 PCS
(G) M4 ALLEN KEY - 1 PC	