




















ASSEMBLY INSTRUCTION

70470




A x 4 	B x 8 	C x 8 	D x 8 	E x 48  Ø8 x30mm
F x 32  Ø7 x70mm	G x16  Ø4 x40mm	H x 1 	I x 1 	

PARTS LIST


		
01 1 PC	02 4 PCS	03 4 PCS
		
04 4 PCS	05 4 PCS	06 4 PCS
		
07 4 PCS	08 4 PCS	09 4 PCS

STEP 1

1




2




STEP 2

1 4x




2 4x



STEP 3

1 4x



2 4x

