












2




1




3


A	 M6X20	4PCS	D		1PC	G	 M6X12	4PCS
B		1PC	E		1PC	H	 M6X20	4PCS
C		1PC	F		2PCS	I		1SE



4




5




6



7



8



9

## HOW TO ADJUST HEADREST

Ajuster appuie-tête  
Ajustar el reposacabezas



To adjust headrest: pull from back on both sides as shown.

Appuie-tête d'ajuster tirez de l'arrière sur les deux côtés

**PARA AJUSTAR-** tirar de ambos lados fom vuelta o usar el brazo para volver reposacabezas



Do not pull from side edge to adjust, material may tear.

ne tirez pas avantage - matériau peut se déchirer - matériau dégâts

no tire de un lado - los daños materiales



To return headrest back: push on both sides or use forearm to evenly move headrest back.

Appuie-tête arrière poussez sur les deux côtés ou utiliser l'avant-bras, comme indiqué

hacer retroceder el reposacabezas-empujar a ambos lados o usar el brazo para empujar de manera uniforme hacia atrás.

**CAUTION-**

Do not push in the center of the headrest as this may cause foam cushion to collapse.

**ATTENTION**

ne poussez pas milieu de tête peut causer des dommages à amortir

**ATTENTION**

no empuje medio de apoyo para la cabeza

